

Intermediate Cable Guide

- Maintains the cable along the scale and allows the rope grab to pass through without any manipulation.
- This cable guide is used to avoid the cable flapping.
- Installed every 8 mtrs.

Model: FA 20 202 00